



* SUB FRAME MEMBERS TO BE INSTALLED HORIZONTALLY OR VERTICALLY AS REQUIRED FOR ATTACHMENT OF EXTERIOR CLADDING. ATTACHMENT FASTENERS TO BE AT LEAST 3" FROM ANY HORIZONTAL PANEL JOINT.