



* SUB FRAME MEMBERS TO BE INSTALLED HORIZONTALLY OR VERTICALLY AS REQUIRED FOR ATTACHMENT OF EXTERIOR CLADDING. ATTACHMENT FASTENERS TO BE AT LEAST 3" FROM ANY HORIZONTAL PANEL JOINT.

C&I HEAD DETAIL

APPLICATION:
COMMERCIAL & INDUSTRIAL

HPCI-WH-01
DATE: OCT. 10, 2011