



* SUB FRAME MEMBERS TO BE INSTALLED HORIZONTALLY
OR VERTICALLY AS REQUIRED FOR ATTACHMENT OF EXTERIOR
CLADDING. ATTACHMENT FASTENERS TO BE AT LEAST 3"
FROM ANY HORIZONTAL PANEL JOINT.

C&I JAMB DETAIL

APPLICATION:
COMMERCIAL & INDUSTRIAL

HPCI-WJ-01
DATE: OCT. 10, 2011