



* SUB FRAME MEMBERS TO BE INSTALLED HORIZONTALLY
 OR VERTICALLY AS REQUIRED FOR ATTACHMENT OF EXTERIOR
 CLADDING. ATTACHMENT FASTENERS TO BE AT LEAST 3"
 FROM ANY HORIZONTAL PANEL JOINT.

C&I PANEL JOINT DETAIL

APPLICATION:
COMMERCIAL & INDUSTRIAL

HPCI-VJ-01
DATE: OCT. 10, 2011