



General Wall Assembly

Notes:

1. See detail HPCI-MP-03 for furring zee design and spacing information.
2. Holes for furring zee attachment are field drilled in the furring zee flanges.
3. On back side of furring zee flanges, butyl sealant pads are applied over attachment holes.
4. Furring zeers are butt joined as required for wall height.
5. Extension channels used where surface clearance is required.

Furring Zee
Installation

HPCI Barrier Panel
w/ Metal Panel Cladding

HPCI-MP-02

Date: Sept. 15, 2012