



**Notes:**

1. See detail HPCI-TC-03 for furring channel design and spacing information.
2. Holes for furring channel attachment are field drilled in the furring channel flanges.
3. On back side of furring channel flanges, butyl sealant pads are applied over attachment holes.
4. Furring channels are butt joined at centerline of respective wall framing stud.

Furring Channel  
Installation

HPCI Barrier Panel  
w/ Terra Cotta Cladding

HPCI-TC-02

Date: August 15, 2012