

1. ADD WALL PANEL THICKNESS (BOTH ENDS) PLUS OUT TO OUT DIMENSIONS OF RAKE STRUCTURAL SUPPORTS.
2. DIVIDE RESULT BY PANEL MODULE* (30", 36" OR 42") TO DETERMINE NUMBER OF PANELS REQUIRED.
3. DIVIDE FRACTIONAL PANEL REMAINDER (IF ANY) BY 2 TO DETERMINE STARTING PANEL WIDTH. IF RESULT IS LESS THAN 12", THEN CUT STARTER PANEL TO REMOVE INTERIOR JOINT ONLY - LAST PANEL WILL NEED TO ACCOMMODATE THE REMAINDER (LAYOUT WILL BE ASYMMETRICAL).

